

CARBON BLOCK FILTER HOUSING REPLACEMENT

This tech note explains what is required should damage occur to the filter housing on the carbon block filtration assembly. This includes the PTG-520[®] Carbon Block Filtration System along with the other carbon block filtration system that utilizes 4.5 x 20” carbon block filters.

If damage has occurred to either style of filter housings on the carbon block filtration system making it unusable, the proper replacement kit is designed to provide a complete replacement all in one part number.

Each kit includes one (1) of the special modified filter housing (both filter cap and filter sump), one (1) drain valve, and includes other useful items. Included in the kit is an instruction sheet, p/n W3T575246, which details the required steps to replace the damaged filter housing. These kits do not include the assembly bracket, pressure gauges, sample ports, or any interconnecting plumbing.

Use the following chart to identify what carbon block filtration system you have in order to determine what filter housing kit is required.

Carbon Block Filtration System Description	Carbon Block Filtration System Part Number	Filter Housing Color (Cap/Sump)	Replacement Filter Housing Kit Part Number
PTG-520	W3T577638	White/White	W3T577704
Non-PTG-520	W3T577974	Black/Blue	W3T578020

Please be sure to contact Technical Support at 888-595-0666 if you have any questions or require further assistance.

PTG-520 is a trademark of Evoqua Water Technologies LLC, its subsidiaries or affiliates in some countries.